




ZoneVu

ZSI-320

INSTALLATION GUIDE

ZoneVu ISDN Gateway Module

- ◆ Connects just like a keyboard
- ◆ Pre-configured



Connection

The module connects to a Zonevu matrix system through the ZVM Port. This Full duplex RS422 port is connected to the Keyboard network with the following connections:

Rx+	to	Tx+
Rx-	to	Tx-
Tx+	to	Rx+
Tx-	to	Rx-
Gnd	to	Gnd

Please refer to your zonevu manual for pinout details of the keyboard network.

The video in connection is fed from an output of the matrix. See notes on configuration below. Optionally the video out can be fed back to a matrix input to view the picture from the video phone.

Configuration

The unit is preset with a **MAC** address of **4**. Care should be taken to ensure that any keyboards connected to the matrix do not use this address.

The unit is pre-configured to switch **output 4** of the matrix, and should therefore be connected to it.

Control will be requested at **priority level 4**, and automatically relinquished after a **60 second timeout**.

Video Phone

The video phone setup menu should be used to set the **protocol** under the Data PC options to **T120**

